

SNO CONE MACHINE



Machine must be properly grounded to prevent shock. BEFORE you plug in the machine, make sure that the wall outlet can accept the (3) prong grounded plug on the power supply cord. 120 Volt, 15amp, single phase, 60 cycle AC current.

TO OPERATE THE MACHINE:

1. Fill the hopper to within an inch from the top with ice cubes or block ice (no larger than 3 to 4 inches). The larger the pieces, the better the snow.
2. Switch the motor on, and wait for it to reach full speed (this will take a minute or so).
3. Press the pusher handle down against the ice in the hopper. Apply firm and even pressure to make the best snow. Practice will enable you to gauge when to stop. This allows the ice to resettle against the shaver head. You may find that you need to relieve the pressure two or three times during a cycle.

TIPS:

- Do NOT force the handle too much, as this can cause the motor to stall.
- Too much pressure on the handle will make the ice come out coarse; and too little pressure makes the ice mushy.
- Make a pile of ice when using the machine as it will keep from melting faster.
- It is normal for the machine to have a surface temperature of 150 F.
- Do NOT let any metal get down the hopper. This will ruin the blades which are tempered steel.
- If you are using the machine indoors, a suggestion would be to use a bucket for the drain hose to collect water. Failure to do so will result in water spilling on the floor.



NEVER put your fingers or any object into the shaving chute while the motor is still running. Since you can be seriously hurt if you disobey these instructions, we do assume any liability for injury due to careless handling or operation of this equipment. Unplug the machine before cleaning or performing any maintenance.

This Table Is Based On 1½ Ounce Of Syrup Per 8 Ounce Cup Of Ice

Size Of Syrup Bottles	Number Of Snow Cones
1 quart	25
1 gallon	100

