

COFFEE MAKER



OPERATING TIPS

1. Fill coffee maker to desired level with COLD water.
2. Add coffee according to manufacturer's recommendations or chart below.
3. Plug coffee maker into proper electrical outlet. You need 12 AMPS.
4. Remove coffee grounds when coffee has finished brewing.

CLEANING INSTRUCTIONS

1. Rinse coffee maker before returning.
2. NEVER IMMERSER COFFEE MAKER IN WATER.

BREWING TIME

30-60 cups	60 minutes
90-100 cups	90 minutes

COFFEE EQUIVALENTS

Number of Cups	Coffee Measure
30	2 cups
55-60	3.5 cups
90	6 cups

NOTE: One pound of coffee is equal to 4.75 cups of ground coffee.

**NEED OUTLET DEDICATED FOR COFFEE POT ONLY.
NO EXTENSION CORD!!!**